




Montageanleitung: Anstellcontainer 1630










(" links ")

oder:

" rechts "



Holzteile (Panel)



Beschlagbeutel (fittings)

4 x (A)



500 302

16 x (B)



(4,5 x 16mm)

500 234

16 x (C)



500 270

4 x (D)



500 578

16 x (E)



500 359

8 x (F)



500 449

2 x (G)



500 516

